

TR-3

SURFACE DISINFECTION



Huwa-San® TR-3, a powerful disinfectant

Huwa-San TR-3 is a broadly applicable surface disinfectant based on an aqueous solution of 3% stabilized hydrogen peroxide (H₂O₂). Due to its unique formulation, Huwa-San TR-3 is highly effective against different types of disease-causing agents and meets the highest EN disinfection standards for bactericides, fungicides and virucides. Additionally, this ready-to-use disinfectant is colourless, odourless and non-corrosive, making it ideally suited for disinfection of a wide range of surfaces in working and living environments.

Intended use

Huwa-San TR-3 is suitable for killing bacteria, fungi and viruses and can be used as general disinfectant on hard surfaces (floors, walls, furniture,...) in industry, institutions (offices, schools, kinder gardens), swimming pools, recreational areas, hotels, indoor and outdoor paved surfaces. Also the highly contagious novel coronavirus, responsible for causing COVID-19, is effectively inactivated by Huwa-San TR-3. In addition, you can also immerse small materials in this ready-to-use solution in order to disinfect them.

Instructions for use

- For clean application, first clean the surfaces thoroughly. Rinse used cleansing agents away with pure water and remove excess water.
- Spray with Huwa-san TR-3 and let the disinfectant impact during appropriate time.
- Spray the surfaces with or immerse the materials in Huwa-san TR-3 and allow the disinfectant to take effect for the appropriate time.
- Use as much liquid as you need to keep the

Benefits

- Efficient bactericide, fungicide & virucide
- Proven effectiveness against coronaviruses (SARS-CoV-2)
- No harmful byproducts
- Free of chlorine and alcohol
- Ready-to-use solution
- Biodegradable, splits in water and oxygen
- Odourless, colourless and non-corrosive
- Long lasting and controlled effect
- EN approved (EN 1276, EN 1650, EN 13697, EN 13727, EN 13624, EN 14476, EN 14348, EN 14561, EN 14562)
- Ecocert certification

MADE IN BELGIUM

Huwa-San®

A sustainable way of disinfection

- surfaces moistened during the disinfection period.
- Let air dry or wipe after the required contact time with a clean cloth.
- No rinsing required. Only material that comes in contact with food must be rinsed with clear water.

TR-3

SURFACE DISINFECTION

Huwa-San® TR-3	
VIRUSES	
Enveloped viruses (including all coronaviruses)	
Application	Contact time
Surface disinfection in clean & dirty conditions	5 min.
Non-enveloped viruses	
Application	Contact time
Surface disinfection in clean conditions	60 min.
BACTERIA, YEAST, FUNGI	
Application	Contact time
Surface disinfection in clean & dirty conditions	5 min.
MYCOBACTERIA	
Application	Contact time
Surface disinfection in clean & dirty conditions	60 min.

Dosage

Ready-to-use solution

Specifications

Appearance: colourless, odourless fluid

Active components: hydrogen peroxide 3%

Density (kg/l at 15°C): 1.010 – 1.012

Biodegradability

Huwa-San TR-3 is biodegradable due to its decomposition into oxygen and water (in accordance with AFNOR T 73-260 directives).

Storage conditions and shelf-life

Store the product in its sealed container at 10°C – 30°C in a dark, low-traffic area. Huwa-San TR-3 should be stored in an **upright position** (↑) and taking account of good warehousing practice. In its closed packaging, the product can be kept for at least 2 years.

Packaging

Trigger spray: 500 mL

Refill containers: 1 L and 5 L

Safety

- Before using the product, read the enclosed safety data sheet carefully.
- Use the appropriate personal protection equipment.
- Keep out of reach of children.
- IF IN EYES: Rinse carefully with water for several minutes. Remove contact lenses, if present and easily done. Continue rinsing. Seek medical advice.
- IF SWALLOWED: do not induce vomiting: seek medical advice immediately and show label, instruction leaflet or packaging.
- The user **MUST** observe the instructions for use, as non-compliance may affect the safety and effectiveness of the product.

Origin of the product

Roam Technology NV • Geleenlaan 24 • B-3600 Genk

T: +32 (0)89 44 00 42 • info@roamtechnology.com

www.roamtechnology.com